
Models EAH, EC, EAH-T, EC-T




Quick Setup Instructions


WARNING: Electrical and plumbing connections need to be made by a licensed service person and comply with all Federal, State and Local Health, Electrical, Plumbing and Safety codes.

MODEL "E" REAR VIEW






Connect a 2" drain pipe (not supplied) from scrap accumulator to floor or wall drain.



Connect dishmachine to hot water source (minimum 120-140 temperature required).




Insert tube stiffener with chemical tubing into each corresponding chemical dispensers.




11-2016











Level dishmachine by adjusting leveling legs. Dishmachine must be level front and back to ensure proper performance.



Press and hold the Fill/Start Switch until the water level is approximately 1/2" to 3/4" below the overflow hole in the PVC standpipe.



Open dishmachine doors completely. Closing the doors will automatically activate the machine.

11-2016

